BDI Plus® Technical Description

Bio-Dechlor INOCULUM Plus (BDI PLUS[®]) is an enriched natural consortium containing species of Dehalococcoides sp. (DHC). BDI PLUS has been shown to simulate the rapid and complete dechlorination of chlorinated solvents such as tetrachloroethene (PCE), trichloroethene (TCE), dichloroethene (DCE) and vinyl chloride (VC) to non-toxic end products, ethene, carbon dioxide and water.

The culture also contains microbes capable of dehalogenating halomethanes (e.g., carbon tetrachloride and chloroform) and haloethanes (e.g., 1,1,1-TCA and 1,1-DCA) as well as mixtures of these contaminants.

For a list of treatable contaminants with the use of BDI PLUS, view the Range of Treatable Contaminants Guide.

Chemical Composition

• Non-hazardous, naturally-occurring, non-altered anaerobic microbes and enzymes in a water-based medium.

Properties

- Appearance Murky, yellow to grey water
- Odor Musty
- pH 6.0 to 8.0
- Density Approximately 1.0 grams per cubic centimeter (0.9 to 1.1 g/cc)
- Solubility Soluble in Water
- Vapor Pressure None
- Non-hazardous

Storage and Handling Guidelines

Storage

Store in original tightly closed container

Store away from incompatible materials

Recommended storage containers: plastic lined steel, plastic, glass, aluminum,

stainless steel, or reinforced fiberglass

Store in a cool, dry area at 4-5°C (39 - 41°F)

Material may be stored for up to 3 weeks at 2-4°C without aeration

Handling	
----------	--

Avoid prolonged exposure

Observe good industrial hygiene practices

Wear appropriate personal protective equipment

Species of Dehalococcoides sp. (DHC)







BDI Plus® Technical Description

Applications

- BDI PLUS is delivered to the site in liquid form and is designed to be injected directly into the saturated zone requiring treatment.
- Most often diluted with de-oxygenated water prior to injection into either hydraulic push injection points or properly constructed injection wells.
- The typical dilution rate of the injected culture is 10 gallons of deoxygenated water to 1 liter of standard BDI PLUS culture.

Application instructions for this product are contained here **BDI Plus Application Instructions**.

Health and Safety

Material is non-hazardous and relatively safe to handle; however avoid contact with eyes and prolonged contact with skin. OSHA Level D personal protection equipment including: vinyl or rubber gloves and safety goggles or a splash shield are recommended when handling this product. An eyewash station is recommended. Please review the Material Safety Data Sheet for additional storage, usage, and handling requirements here: <u>BDI PLUS SDS</u>.



www.regenesis.com Corporate Headquarters 1011 Calle Sombra, San Clemente CA 92673 949.366.8000

Cambridge House, Henry Street, Bath BA1 1BT, United Kingdom europe@regenesis.com

©2015 All rights reserved. Regenesis and BDI PLUS® is a registered trademark of Regenesis Bioremediation Products. All other trademarks are the property of their respective owners. SS19_01